


RADIANT COMFORT™

Hydronic In-floor Insulation Panels Nailed Hardwood Flooring Installation Detail



Required fasteners*: **Foam adhesive, 1" brad nails, 1-1/4" cleat nails**

- 1) Use **foam adhesive** to fasten Radiant Comfort to the structural subfloor.
- 2) After 30 minutes, or when foam adhesive is set, walk the tubing into Radiant Comfort. Use a tubing de-coiler to unwind the tubing and prevent kinks.
- 3) Use **foam adhesive** to fasten the 3/4" plywood at the Radiant Comfort puck centers
- 4) Lay 3/4" plywood over Radiant Comfort.
- 5) Lay hardwood flooring paper over the 3/4" plywood.
- 6) Use **1" brad nails** to fasten the 3/4" hardwood flooring from the top vertically.
- 7) Use **1-1/4" cleat nails** to fasten the 3/4" hardwood flooring from the tongue at 45 degrees.

*Please refer to the Radiant Comfort installation instruction sheet prior to using this detail.